


LST TOOL HANGER




The LST Tool Hanger mounts onto three fastening points (A), (B), and (C) to safely and securely fit all models and sizes of the LITHIUM SERIES® II Tool.



STEP 1: Position the LST Tool Hanger over the tool as shown. Align locating pin (C) with the tool's insert hole. Slide locating pin firmly into hole.



STEP 2: Pivot down the LST Tool Hanger so captive screws (A) and (B) align with the tapped holes on both sides of the tool. Hand-tighten both captive screws and the wing nut on locating pin (C) until fully secured. Take caution not to cross threads.



STEP 3: The adjustable eyelet allows better balance of the tool when equipped with various sockets and reaction arms. Push down the thumb lever (D) and adjust the sliding beam (E) to the desired position.

*Not visible.

HYTORC owns all content, copyrights, trademarks and patents in this document. © 2021 HYTORC. Any unauthorized use or distribution of any material from this document is strictly prohibited.